

NM-I2011

NOCUTA MOUNTING KIT



Continuing Noctua's tradition of supplying customers with its premium-class SecuFirm2™ mountings free of charge, the NM-I2011 kit allows Noctua users to upgrade to Intel's LGA2011 socket for Core i7-39xx/38xx processors. The NM-I2011 set is backwards compatible with all Noctua retail coolers since 2005 and has been designed to combine outstanding reliability, optimal contact pressure and easy, straightforward installation. Bringing the trusted SecuFirm2™ quality to Intel's new LGA2011 platform, NM-I2011 is an enthusiast-grade mounting that meets the highest demands in safety, performance and ease-of-use.

LOGISTICAL DATA

Product Labeling

Noctua NM-I2011

EAN-No.

471612331468-4

UPC-No.

84243101402-3

Dimensions (HxWxD)

130 x 115 x 25 mm

Weight

170 gr

Warranty

6 Years

MSRP

5.90 EUR

Packaging Unit

80 Pcs.

Dimensions / Unit (HxWxD)

515 x 285 x 260 mm

Weight / Unit

14.50 kg

SCOPE OF DELIVERY

2x NM-IMB2 Mounting-Bars

2x NM-IFB2 Fastening Brackets

4x NM-IBT2 Bolts

4x NM-SSC1 Short Screws

4x NM-ITS1 Thumbscrews

Trusted SecuFirm2™ Quality

Over the years, SecuFirm2™ has become synonymous with impeccable long-term stability and flawless craftsmanship. Enthusiast users and industry clients alike trust the time-tested quality of Noctua's professional mounting systems.

Perfect Contact Pressure

SecuFirm2™ mounting systems use high-grade coil springs to achieve perfect contact pressure. No guesswork regarding how far to tighten the mounting screws, no risk of damaging the socket with excessive pressure!

Integrated Fastening Brackets

Noctua's SecuFirm2™ systems feature fully integrated fastening brackets with pre-fixed pressure screws and springs, which greatly facilitates the installation process. No fiddling with loose screws and springs!

Tailor made for LGA2011

In order to cut costs, many manufacturers use cross-platform parts for both Intel and AMD, which can cause compatibility issues. Noctua's NM-I2011 has been tailor-made for LGA2011 and strictly complies to the Intel keep-out zones in order to ensure 100% compatibility.

Backwards Compatibility

The NM-I2011 SecuFirm2™ kit is fully backwards compatible with all Noctua retail coolers since 2005, making them safe long-term investments that can be used for several CPU generations.

Product Specifications

Socket compatibility

LGA2011

Supported CPU series

Intel Core i7 39xx & 38xx

Cooler compatibility

Noctua NH-C12P, NH-C12P SE14.

NH-C14, NH-D14, NH-U12F, NH-U12.

NH-U12P, NH-U12P SE1366.

NH-U12P SE2, NH-U9, NH-U9F.

NH-U9B, NH-U9B SE2

