

Technical Details:

- Supports Socket AM4
- Ports: G1/4"
- LED Holes: 2x5x5mm


Box Contents:

- 1x RayStorm Edge Waterblock
- 1x RGB Needle Connector
- 1x AM4 Screw Set
- 1x K3 Thermal Paste



The installation process below is shown without the tubing connected. This has been done so the installation process can be seen clearly. All watercooling components should be connected and leak tested prior to installation into a PC.

Preparing Socket AM4



1. Remove the plastic clips on either side of the CPU socket by undoing the 4 screws.



2. If the backplate is loose, place it back in its correct position. Make sure the 4 screw threads on the backplate line up with the holes on the motherboard.




3. Screw the posts into each of the four holes around the socket.



Continue over page >

Fitting the Waterblock (AM4)

The installation process below is shown without the tubing connected. This has been done so the installation process can be seen clearly, without any obstructions.




1. Remove the plastic film from the base of the waterblock.



2. Apply a thin layer of thermal paste to the CPU's heat spreader.




3. Place the waterblock over the posts and onto the CPU.




4. Place a spring over each of the four posts and into the wells on the hold down bracket.



5. Place a nut onto each post and gradually tighten them. You should tighten each nut in stages. e.g. 1,2,3,4,1,2,3,4,1,2,3,4, until each nut is fully tightened.



6. Connect the 5v 3pin aRGB plug to your motherboard RGB header or RGB controller.



8. The block is now ready to use. When you first boot it is advisable to use software to check the core temperature. If the temperature is high you will need to remount the block.